



Temperature charts for 4-cell Kentax UHV Evaporator TCE


Temperature curves of 4-cell evaporator TCE
with (starting with ice water)
and without cooling



Temperature curves of 4-cell evaporator TCE
with (ice water)
and without cooling




Temperature curves of 4-cell
evaporator TCE
with (ice water)
and without cooling




Temperature curves of 4-cell evaporator TCE
with (starting with ice water)
and without cooling


T1 is heated
T2, T3 and T4 are not heated




Temperature curves of 4-cell evaporator TCE
with (ice water)
and without cooling



Temperature curves of 4-cell evaporator TCE
with (ice water)
and without cooling




Temperature curves of 4-cell evaporator TCE
with (ice water)
and without cooling




Temperature curves of 4-cell evaporator TCE with cooling (ice water)

T1 is heated
T2, T3 and T4 are not heated




Temperature curves of 4-cell evaporator TCE
with cooling (ice water)

T1 is heated
T2, T3 and T4 are not heated




Temperature curves of 4-cell evaporator TCE with cooling (ice water)

T1 is heated
T2, T3 and T4 are not heated



Temperature curves of 4-cell evaporator TCE
with cooling (ice water)

T1 is heated
T2, T3 and T4 are not heated



Temperature curves of 4-cell evaporator TCE
with cooling (ice water)

T1 is heated
T2, T3 and T4 are not heated

